

JENEsys® Edge 534

INSTALLATION GUIDE — NIAGARA AX

Package Contents of JENE-EG534

Estimated installation time: 5-10 minutes

- ✓ (1) JENEsys® Edge 534 (*JENE-EG534*)
- ✓ This JENEsys Edge 534 Installation Guide
- ✓ (1) JENEsys Edge 534 Wiring Installation Guide
- ✓ (1) 15-Position Terminal Connector (*blue*)
- ✓ (3) 12-Position Terminal Connectors (*2 black & 1 blue*)
- ✓ (4) 3-Position Terminal Connectors (*1 black, 1 gray & 2 blue*)



Preparing to Install

Decide on the location/placement of your JENEsys Edge 534. You can use wall mounting screws (*not provided*) to mount the device in an open space or mount on a 35mm wide DIN rail utilizing the molded DIN rail slot located on the base of the device. Make sure the selected location is:

- ✓ Not in direct sunlight or near a heater or heating vent
- ✓ Not cluttered/crowded and sufficient clearance is available above and below the JENEsys EDGE 534 for proper ventilation and room for cables and wiring
- ✓ Well-ventilated (*especially if enclosed in a cabinet*)
- ✓ Be sure to download the AX version of the Onyx Driver at: resources.lynxspring.com.

Physical Mounting to a DIN Rail

For UL safety compliance this LynxSpring product shall be mounted inside enclosures with no openings below the device and if non-metallic, a flammability rating of at least HB.

- Step 1:** Position the JENEsys Edge 534 on the rail, tilting to hook DIN rail tabs over one edge of the DIN rail.
- Step 2:** Pull out the DIN rail clip and push down and in to force the DIN rail clip to snap over the other edge of the DIN rail.
- Step 3:** To keep the JENEsys Edge 534 from sliding on the DIN rail, secure it with clips provided by the DIN rail vendor, or place a screw in one of the mounting tabs in the base of the JENEsys Edge 534.

Note 1: Up to eight Onyx XM 34IOs can be connected in any orientation. See section: [CONNECTING ONYXX NETWORKS TO JENESYS EDGE 534](#) for details.

Note 2: To remove the device(s) from a DIN rail, insert a screwdriver in center plastic locking tab and pull downwards, then lift the unit outwards.

Connecting to the JENEsys Edge 534

A 10/100-Mbit Ethernet connection is available on the JENEsys Edge 534. This is an RJ-45 port. The RJ-45 port has two LEDs. When the device is connected to a network, the blue **LINK** LED is lit and the blue **ACTIVITY** LED flashes when activity occurs.

Step 1: Connect one end of the Ethernet cable to your JENEsys Edge 534's Primary RJ-45 port and the other end to the internet port on your computer.

Step 2: Unplug the 3-position screw terminal (black) from the Power port on the JENEsys Edge 534.

Step 3: Insert the *positive* wire from your 24Vac, 50/60 Hz circuit to the terminal marked $\sim/+$ on the screw terminal and tighten down the screw.

Step 4: Insert the *negative* wire from your 24Vac, 50/60 Hz circuit to the terminal marked $\sim/-$ on the screw terminal and tighten down the screw.

Step 5: Insert the *ground* wire from your 24Vac, 50/60 Hz circuit to ground (*far left terminal*) marked \perp on the screw terminal and tighten down the screw.


Step 6: Plug the 3-position screw terminal connector back into the Power port on the JENEsys Edge 534.

Step 7: Temporarily change your computer's network settings so your IP address is in the range: **192.168.1.1** to **192.168.1.254** (*without using the JENEsys Edge 534's default address as described in Step 8*). Make note of your computer's current network settings.

Step 8: With ProBuilder 3.8.111/Workbench 3.8.111 installed on your computer, make a platform connection to the JENEsys Edge 534 using the factory default IP address (*192.168.1.12n*, where the last numeral (*n*) matches the last numeral in the JENEsys Edge 534's Host ID number), platform daemon port (3011), and the following credentials:

Username: tridium
Password: niagara

Step 9: Refer to the NIAGARA AX USER GUIDE and JENEsys EDGE 534's NIAGARA USER GUIDE for detailed instructions on how to configure it using Niagara.



Connecting RS-485 Networks to JENEsys Edge 534

The RS-485 ports use a 3-position, screw terminal connector. The screw terminals (*from left-to-right*) are shield, negative (-), and positive (+). The transmit (Tx) and receive (Rx) LEDs located on the JENEsys Edge 534 cover will flash when there is network activity detected.

Step 1: Unplug 3-position screw terminal connector from either RS-485 port on the device.

Step 2: Insert positive wire from your RS-485 network to positive terminal (*far right terminal*) on the 3-position, screw terminal connector and tighten down the screw.

Step 3: Insert negative wire from your RS-485 network to negative terminal (*center terminal*) on the 3-position, screw terminal connector and tighten down the screw.

Step 4: Insert shield wire to shield terminal (*far left terminal*) on the 3-position, screw terminal connector and tighten down the screw.

Step 5: If the Onyx XM 34IO is located at the end of the network, LynxSpring recommends installation of a 120 ohm end-of-line resistor on the positive (+) and negative (-) terminals.



Step 6: Plug 3-position screw terminal connector back into the RS-485 port.



RECOMMENDED RS-485 CABLE SPECIFICATION

| | |
|---------------------------------------|--------------|
| Max Cable Length | 4,000 feet |
| Min loaded driver output signal level | ± 1.5v |
| Driver load impedance (Ohms) | 54 |
| Receiver input voltage range | -7v to + 12v |
| Receiver input resistance (Ohms) | ≥12k |

Specifications

| PLATFORM | |
|-----------------------|--|
| Operating System | Helixx [®] by Lynxspring [®] and Niagara Framework [®] AX 3.8.111 |
| Processor | 1 GHz AM335x ARM Cortex A-8 |
| Memory | 512 MB DDR3L 800 MHz, 4 GB 8-bit Embedded MMC on-board Flash |
| Real-Time Clock (RTC) | Battery-powered clock included to store description/setup values including: year, month, date, hours, minutes and seconds. |

| COMMUNICATION PORTS | |
|---------------------|--|
| 2 Ethernet Ports | 10/100 Mbps (RJ-45 Connector) |
| 2 RS-485 Ports | Optically-isolated RS-485 serial port with 3-screw connector |
| Mini B-USB | USB Client Connector utilizes 5-pin Mini-B USB cable |
| Micro USB | Serial shell access |
| Onyxx Network | 3-wire (LxH LxL SHLD) high-speed differential serial signal |

| INPUTS & OUTPUTS | |
|----------------------|---|
| 16 Universal Inputs | Type-3 10 K ohm thermistors; resistance 0-100 K ohms; 0-10 Vdc; 0-20 mA using a 499 ohm resistor; pulse input: up to 500 Hz |
| 10 Digital Outputs | Form A contacts, 24 V at 0.5 A |
| 8 Analog Outputs | 0-10 Vdc |
| Connector Screw Size | 3/32" slotted |
| Supported Wire Size | 28-16 AWG |
| Housing | UL94V-0 |

| POWER | |
|-------------|--|
| Power Input | External 24 Vac +0%/-10%, dc +10%/-10%, minimum 18 VA/device |

| CHASSIS | |
|--------------|--|
| Construction | Base: Plastic, DIN rail or screw mount Cover: Plastic |
| Cooling | Internal air convection |
| Dimensions | 4.5" (11.43 cm) width x 4.25" (10.8 cm) length x 2.25" (5.72 cm) depth |
| Mounting | Flat panel and 35 mm DIN rail mounting options standard |

| ENVIRONMENT | |
|-----------------------------|----------------------------|
| Operating Temperature Range | 0 – 60 °C (32 –140 °F) |
| Storage Temperature Range | 0 – 70 °C (32 –158 °F) |
| Relative Humidity Range | 5 – 95% RH, non-condensing |

| CERTIFICATIONS | |
|----------------|--|
| Compliance | Approved: FCC 47CFR Parts 15B and 18, EN 55022, EN 55011, ICES-003, RoHS, UL 916, CSA C22.2 No. 205-17 In Process: EN 61010-1: 2010, IEC 61010-1, 3rd edition |

Revised 5/11/2018 | JENE-EG534-V1

Connecting Onyxx Networks (Onyxx XM 3410 to JENEsys Edge 534)

Step 1: Unplug 3-position screw terminal connector (gray) from port marked LxH, LxL and SHLD on the JENEsys Edge 534.

Step 2: Insert a wire between LxH terminal (*far left terminal*) on the 3-position screw terminal connector of each device and tighten down the screw.

Step 3: Insert a wire between LxL terminal (*center terminal*) on the 3-position screw terminal connector of each device and tighten down the screw.

Step 4: Insert the shield wire between SHLD terminal (*far right terminal*) on the 3-position screw terminal connect of each device and tighten the screw.

Step 5: If the Onyxx XM is located at the end of the network, Lynxspring recommends install of a 120 ohm end-of-line resistor on the LxH and LxL terminals.

Step 6: Plug 3-position screw terminal connector back into the port marked LxH, LxL and SHLD on the JENEsys Edge 534 and Onyxx XM 3410 as needed.

Troubleshooting

If you are unable to make a platform connection to the JENEsys Edge 534:

- ✓ Make sure the JENEsys Edge 534 is fully up and running. The power LED should turn on and the heartbeat LED should be flashing.
- ✓ Make sure the Ethernet cable is connected firmly to the primary Ethernet port on the JENEsys Edge 534. The LEDs on the Ethernet port will indicate if the JENEsys Edge 534 is connected to the network. The blue **LINK** LED will indicate the JENEsys Edge 534 is connected to a network and additional blue **ACTIVITY** LEDs will indicate the JENEsys Edge 534 is transmitting and receiving on the network.
- ✓ If you are connecting directly from your computer to the JENEsys Edge 534 ensure your computer's network settings are set so that your computer's IP address is anything other than the device.
- ✓ If you are connecting the JENEsys Edge 534 through a network make sure your computer's network setting is set to **DHCP**.
- ✓ Close and re-open the browser to make sure that the browser does not cache the previous page.

Statement of Conditions

In the interest of improving internal design, operational function, and/or operability, Lynxspring reserves the right to make changes to the product described in this document without notice. Lynxspring does not assume any liability that may occur due to the use or application of the product(s) or circuit layout(s) described herein.

Technical Support

Thank you for selecting Lynxspring products. Please contact our Support Team with any questions about installing or setting up your new JENEsys Edge 534 (*JENE-EG534*).
support@lynxspring.com | toll free: 877-649-5969

Proper Disposal

This product contains a lithium battery.

The U.S. Environmental Protection Agency (EPA) does not regulate the disposal of batteries in small quantities; large quantities are regulated under the Universal rules of Hazardous Waste regulations (*40 CFR PART 273*). Lithium batteries are not currently being collected by manufacturers for recycling. While there are no federal regulations for disposal of lithium batteries, individual states can establish their own guidelines for battery disposal, and should be contacted for any local disposal guidelines.

The shipment of live or discharged lithium batteries is governed by the Department of Transportation (DOT) in their Code of Federal Regulations (49 CFR), paragraph 173.185(j). *Remember that before any type of disposal the batteries should be discharged completely. Tape the contacts with electrical tape and package so as to prevent contacts accidentally coming together at any time.*



This symbol was placed in accordance with the European Union Directive 2002/96 on the Waste Electric and Electronic Equipment (*the WEEE Directive*). If disposed of within the European Union, this product should be treated and recycled in accordance with the laws of your jurisdiction implementing the WEEE Directive.

© 2018 by Lynxspring, Inc. All rights reserved. The information and/or specifications published here are current as of the date of publication of this document. Lynxspring, Inc. reserves the right to change or modify specifications without prior notice. The latest product specifications can be found by contacting our corporate headquarters in Lee's Summit, Missouri. Products or features contained herein are covered by one or more United States or foreign patents. Other brand and product names are trademarks or registered trademarks of their respective holders. This document may be copied by parties who are authorized to distribute Lynxspring products in connection with distribution of those products, subject to the contracts that authorize such distribution. It may not otherwise, in whole or in part, be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form without prior written consent from Lynxspring, Inc. Complete Confidentiality, Trademark, Copyright and Patent notifications can be found at:

<http://resources.lynxspring.com>

Lynxspring,[®] JENEsys,[®] Onyxx,[®] and Helixx[®] are registered trademarks of Lynxspring, Inc.

JENEsys Edge[™] is a trademark of Lynxspring, Inc.

Niagara Framework[®] is a registered trademark of Tridium, Inc.



Corporate Headquarters
1210 NE Windsor Drive
Lee's Summit, MO 64086
P: 816-347-3500 | F: 816-347-0780