

READ BEFORE FLIGHT

IMPORTANT

Powering and Wiring – Important Safety Notes

Please carefully read and follow the instructions found in the Installation Guide and the Wiring Installation Guide, as well as on our YouTube channel at www.youtube.com/lynxspring, for powering and wiring the JENEsys® Edge™ 534, Onyx® XM 34IO and Onyx® XM 34IO-B devices. Following those instructions will help prevent device issues, ensure safety and guarantee the optimal operation of your device(s).

Note 1: Be sure to connect all ports and cables prior to powering up the device.

Note 2: Power supply is to be dedicated to power JENEsys Edge 534 & Onyx XM 34IO devices. DO NOT connect other equipment to this dedicated power supply.

Note 3: Screw down all connector screws prior to testing/installation. Please refer to the wiring guides on our website with the following links and the videos on our YouTube channel with the QR code below:

<http://www.lynxspring.com/technology/jenesys-edge>

<http://www.lynxspring.com/technology/onyxx>

